



# Dell Inspiron 15-3521 Battery Replacement

This guide will instruct users on how to replace the battery of their Dell Inspiron 15-3521 laptop.

Written By: Stephen Landeene



## INTRODUCTION

After extended periods of time, laptop computer batteries will lose the ability to hold a charge and may need to be replaced with a new battery.

---




## PARTS:

- [Dell Inspiron 15-3521 Replacement Battery](#) (1)
-

## Step 1 — Removing the Battery



 We are removing the battery to avoid the possibility of an electrical discharge when working with this system.

- Flip the laptop over.
- Slide the latches toward the outside of the laptop to unlock the battery.
- Lift the battery out of the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 07:49:25 AM.